

Necessary Bandwidth Description

The necessary bandwidth is calculated using the unmodulated pulse emission formula found in § 2.202:

$$B_n = \frac{2 * K}{t}$$

where  $K = 5$  and  $t = 4 \mu\text{s}$ , therefore,  $B_n = 2.5 \text{ MHz}$ .